


Your kit includes a multifunction handle and special attachable tip. These will assist you take your socks off and to guide your foot into the shoe (shoe horn).

Use the following steps to use the Sockee tip.


1. Remove the handle from the Sockee base by pressing the button on the base.

2. Attach the Sockee tip by pressing its button.




## SOCKEE REMOVER

Slide the Sockee tip down the back of your leg, between your calf and sock, and push the handle down until you have removed the sock.



## SOCKEE SHOE HORN

Slide the Sockee shoe horn down between the heel of your foot and shoe lip, push your leg down until your foot slides into the shoe. Pull the Sockee shoe horn up and out of the shoe.



## SOCKEE USER GUIDE

Sockee assists you in getting your socks on and taking them off, independently.

Sockee is the best solution for anyone with mobility or flexibility issues.

Although Sockee is easy to use, it might take some time finding the most comfortable way to use it.

Please be patient, take your time, read this user guide carefully and if necessary, try to use a different chair or different socks. Once you get used to Sockee, your quality of life is going to change...

### WARNING

The Sockee device is not suitable for people with stability or balance problems, or people who require support and/or assistance sitting, standing or walking.

### WHAT YOU WILL NEED

1. A "kitchen" chair with accessible legs
2. Your socks. Socks should be clean and dry. For best results It is recommended to use socks that are no longer than 10" length (heel to top). Preferably use cotton or woolen socks. The Sockee is less effective with thin nylon socks and might not work with nylon stockings.
3. A table or stool to rest the Sockee device on while you prepare it for action.

# INSTRUCTIONS FOR USE


Open the box and remove the Sockee device, the handle and the accessories.

1




Attach the handle to the base by pressing the button, until it clicks. The Sockee device is now ready for use.

2




Raise the Sockee arm to an upright position. Place the sock so that the heel of the sock faces inwards and towards you.

3




Place the sock over the Sockee arm up to the stopper bump.

4




Lightly compress the sock down over the arm, leave the sock end 2-3" loose to make room to your feet

5




If necessary, adjust the hook to a convenient length. (You may need to use the Sockee a few times to find the hook's ideal position suited to you).

6





Lower the Sockee arm to a horizontal position, hold the handle and lower the Sockee to the floor.

7



Anchor the hook around a chair leg, in order to stop it moving.

8



While sitting comfortably upright on the chair, move the Sockee arm with your leg to face the outer side of the chair. Pull your leg back slightly around the outer side of the chair, and slide your foot into the sock. As your heel reaches the edge of the Sockee arm, raise your foot slightly then push your leg down while banding your heel toward you. (in case you are using long socks, finalize the action by pulling the socks up with your hands) Repeat steps 3-10 to put on your other sock.